



Towing and Suspension Solutions

855016-01 05/13

InvisiBrake second vehicle hose kit

part number 98710

Installation instructions

All specifications are subject to change without notice.

ROADMASTER, Inc. 6110 NE 127th Ave. Vancouver, WA 98682 800-669-9690 Fax: 360-735-9300 www.roadmasterinc.com

Purpose

This kit assumes the installer has removed all InvisiBrake components from the original vehicle, with the exception of the hoses. This kit contains those replacement hoses.

To install this kit...

...follow the instructions that came with the original InvisiBrake or visit <http://www.roadmasterinc.com/support/manuals.html> for a copy of the most current instructions.

Kit components

quan.	part number	description
1	450700	1/4" nylon vacuum line, 15 feet
2	450701	1/8" air line, 17 feet
3	452116	1/2" vacuum line tee
4	456118	3/8" vacuum line tee
5	452136	1/2" rubber vacuum hose, 3 inches
6	452111	1/4" rubber vacuum hose, 3 inches
7	452137	3/8" rubber vacuum hose, 3 inches



WARNING

Follow the installation instructions – either those which came with the InvisiBrake, or which you obtain at <http://www.roadmasterinc.com/support/manuals.html>. Property damage, personal injury or even death may occur if the installation instructions are not followed.