



## Combined RSS Application Guide

Following are the applications for the Roadmaster Suspension Solutions family of products. Our products are made with the finest materials available to provide you with a safe and stable ride.

Roadmaster Inc. 6110 NE 127th Ave. Vancouver, WA 98682 1-800-669-9690 Fax: 503-288-8900  
www.roadmasterinc.com

Model	Sub-Assembly	Year	Item #	Comments	Category	Notes
<b>BEAVER</b>						
MISC	Class A	1989 – 1994	RBK6	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
MISC	Class A	1989 – 1994	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	

<b>CHEVROLET</b>						
1500 VAN	Passenger Van	2013 – 2018	RBK23	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
1500 VAN	Passenger Van	2013 – 2018	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
1500 VAN	STEERING BOX OUTSIDE FRAME	1971 – 1995	RBK1	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
1500 VAN	STEERING BOX OUTSIDE FRAME	1971 – 1995	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
1500 VAN	Van/Pick-Up	1995 – 2004	RBK15	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
1500 VAN	Van/Pick-Up	1995 – 2004	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
1500 VAN	Van/Pick-Up WITH DUAL CROSS MEMBERS	2004 – 2013	RBK17	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
1500 VAN	Van/Pick-Up WITH DUAL CROSS MEMBERS	2004 – 2013	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
2500 CLASS C	Class C	1995 – 2004	RBK15	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
2500 CLASS C	Class C	2013 – 2018	RBK23	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
2500 CLASS C	Class C	1995 – 2004	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
2500 CLASS C	Class C	2013 – 2018	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
2500 CLASS C	Class C WITH DUAL CROSS MEMBERS	2004 – 2013	RBK17	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
2500 CLASS C	Class C WITH DUAL CROSS MEMBERS	2004 – 2013	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
2500 CLASS C	STEERING BOX OUTSIDE FRAME	1971 – 1995	RBK1	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
2500 CLASS C	STEERING BOX OUTSIDE FRAME	1971 – 1995	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
2500 CUTAWAY	Cutaway	1995 – 2004	RBK15	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
2500 CUTAWAY	Cutaway	1995 – 2004	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
2500 CUTAWAY	Cutaway/Van	2013 – 2018	RBK23	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
2500 CUTAWAY	Cutaway/Van	2013 – 2018	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
2500 CUTAWAY	Cutaway/Van WITH DUAL CROSS MEMBERS	2004 – 2013	RBK17	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
2500 CUTAWAY	Cutaway/Van WITH DUAL CROSS MEMBERS	2004 – 2013	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
2500 CUTAWAY	STEERING BOX OUTSIDE FRAME	1971 – 1995	RBK1	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	



Model	Sub-Assembly	Year	Item #	Comments	Category	Notes
KODIAK C4500	Cutaway	2003 – 2010	RBK5	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
KODIAK C4500	Cutaway	2003 – 2010	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
KODIAK C5500	Cutaway	2003 – 2010	RBK5	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
KODIAK C5500	Cutaway	2003 – 2010	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
P SERIES		1981 – 2006	RSSP30	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
P SERIES	P30/P32/P3500	1998 – 2006	RSSCP30	Replaces OEM dampener.	Reflex	
P SERIES	P30/P32/P3500	1998 – 2006	RSDP30	Replaces OEM dampener. No return-to-center feature.	Reflex	
P SERIES	P30/P32/P3500	1981 – 2006	RBK3	Coil spring IFS (not for widebody). The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSP30.	Reflex	
P72-P92	Class A	1996 – 1997	RBK6	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
P72-P92	Class A	1996 – 1997	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
SILVERADO 1500 PICK-UP	2WD SUV	1998 – 2004	RBK15	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
SILVERADO 1500 PICK-UP	2WD Van/Pick-Up	1998 – 2004	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	

### COUNTRY COACH

INTRIGUE	Class A	1994 – 1998	RBK10	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
INTRIGUE	Class A	1994 – 1998	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	

### DODGE

M-300/M-500	Class A	1973 – 1981	RBK8	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
M-300/M-500	Class A	1973 – 1981	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
RAM 2500 PICK-UP		2018 – 2021	RBK27	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
RAM 2500 PICK-UP		2018 – 2021	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
RAM 2500 PICK-UP	Truck	2003 – 2008	RBK20	Replaces OEM dampener. The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSB.	Reflex	64
RAM 2500 PICK-UP	truck	2003 – 2008	RSSB	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	64
RAM 3500 PICK-UP		2018 – 2021	RBK27	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
RAM 3500 PICK-UP		2018 – 2021	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
RAM 3500 PICK-UP	RAM 3500 PICK-UP	2003 – 2008	RBK20	Replaces OEM dampener. The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSB.	Reflex	64
RAM 3500 PICK-UP	RAM 3500 PICK-UP	2003 – 2008	RSSB	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	64

### FORD

E250	Van/Pick-Up	1987 – 2022	RBK24	For V8 models with OEM steering dampener. The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
E250	Van/Pick-Up	1987 – 2022	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
E250	Van/Pick-Up V8 WITHOUT OEM STEERING DAMPENER	1987 – 2016	RBK2	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
E250	Van/Pick-Up V8 WITHOUT OEM STEERING DAMPENER	1987 – 2022	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
E350	Class C	1987 – 2022	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
E350	Class C	1987 – 2022	RBK24	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
E350	Class C	1987 – 2022	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	

<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Category</u>	<u>Notes</u>
E350	Van/Pick-Up	1987 — 2022	RBK24	For V10 models. The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
E350	Van/Pick-Up V8 WITHOUT OEM STEERING DAMPENER	1987 — 2016	RBK2	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
E350	Van/Pick-Up V8 WITHOUT OEM STEERING DAMPENER	1987 — 2022	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
E350 CLASS A	Class A	2014 — 2022	RBK24	For V10 models with OEM steering dampener and Thor Axis and Vegas models only. The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
E350 CLASS A	Class A	2014 — 2022	RSSC	For V10 models with OEM steering dampener and Thor Axis and Vegas models only. The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
E450	Class C	1987 — 2022	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
E450	Class C	1987 — 2022	RBK24	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
E450	Cutaway/Van	1987 — 2022	RBK24	For V-8 models. The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
E450	Cutaway/Van	1987 — 2022	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
E450	Cutaway/Van V8 WITHOUT OEM STEERING DAMPENER	1987 — 2016	RBK2	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
E450	Cutaway/Van V8 WITHOUT OEM STEERING DAMPENER	1987 — 2022	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
E450 CLASS A	Class A	1987 — 2022	RBK24	For models with OEM steering dampener and Thor Axis and Vegas models only. The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
E450 CLASS A	Class A	1987 — 2022	RSSC	For V10 models with OEM steering dampener and Thor Axis and Vegas models only. The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
EXCURSION	SUV	2000 — 2005	RBK16	Fits 4x4 models only. The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSB.	Reflex	79
EXCURSION	SUV	2000 — 2005	RSSB	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
F250 PICK-UP	Truck	1999 — 2007	RBK16	Fits 4x4 models only. The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSB.	Reflex	79
F250 PICK-UP	Truck	1999 — 2007	RSSB	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
F350 PICK-UP	Truck	1999 — 2007	RBK16	Fits 4x4 models only. The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSB.	Reflex	79
F350 PICK-UP	Truck	1999 — 2007	RSSB	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
F53 CLASS A	Class A	2017 — 2019	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	75
F53 CLASS A	Class A V10	1999 — 2016	RBK22	For coaches with V10 engines. The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	1
F53 CLASS A	Class A V10	2017 — 2019	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	1,75
F53 CLASS A	Class A V10	1999 — 2016	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
F53 CLASS A	Class A V-10	2017 — 2019	RBK22	Will not work with coaches over 24,000 lbs GVW. V-10 only. The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	1,75
F53 CLASS A	Class A V-10	2017 — 2019	RBK25	For coaches over 24,000 lb GVW only. V-10 only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	75
F53 CLASS A	Class A V8	1989 — 1999	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
F53 CLASS A	Class A V8 and V10	1989 — 1999	RBK4	For coaches with V8 and V10 engines. The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	

<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Category</u>	<u>Notes</u>
F53 CLASS A V-10	Class A V-10	2020 — 2020	RBK25	For coaches over 24,000 lbs GVW ONLY. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	75
F53 CLASS A V-10	Class A V-10	2020 — 2020	RBK22	For coaches under 23,999 lbs GVW. The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	1,75
F53 CLASS A V-10	Class A V-10	2020 — 2020	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	1,75
F53 CLASS A V-10	Class A V-10	2020 — 2020	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	75
F53 CLASS A V-8		2020 — 2022	RBK29	For 16k-26k models only. The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
F53 CLASS A V-8		2020 — 2022	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
F550 CLASS A	Class A	2017 — 2019	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	75
F550 CLASS A	Class A V10	1999 — 2016	RBK22	For coaches with V10 engines. The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	1
F550 CLASS A	Class A V10	1999 — 2016	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	1
F550 CLASS A	Class A V10	2017 — 2019	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	1,75
F550 CLASS A	Class A V-10	2017 — 2019	RBK22	Will not work with coaches over 24,000 lbs GVW. V-10 only. The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	1,75
F550 CLASS A	Class A V-10	2017 — 2019	RBK25	For coaches over 24,000 lb GVW only. V-10 only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	75
F550 CLASS A	Class A V8	1989 — 1999	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
F550 CLASS A	Class A V8 and V10	1989 — 1999	RBK4	For coaches with V8 and V10 engines. The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
F550 CLASS C		2019 — 2021	RBK28	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
F550 CLASS C		2019 — 2021	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
F550 TRUCK		2019 — 2021	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
F550 TRUCK		2019 — 2021	RBK28	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	

### **FREIGHTLINER**

AIR SUSPENSION	SOLID FRONT AXLE	1995 — 2005	RBK14	Does not fit models with 150 gallon fuel tank. The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
AIR SUSPENSION	SOLID FRONT AXLE	1995 — 2005	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
FL SERIES	FL50,FL60	1991 — 2002	RBK8	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
FL SERIES	FL50,FL60	1991 — 2002	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
M2	Class C	2003 — 2020	RBK8	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
M2	Class C	2003 — 2020	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
S2RV		2018 — 2020	RBK26	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
S2RV		2018 — 2020	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
XC CHASSIS	SOLID FRONT AXLE	2006 — 2018	RBK18	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA. No XCR chassis.	Reflex	
XC CHASSIS	SOLID FRONT AXLE	2006 — 2018	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
XC CHASSIS	SOLID FRONT AXLE	2006 — 2018	RBK18	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA. No XCR chassis.	Reflex	
XC CHASSIS	SOLID FRONT AXLE	2006 — 2018	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
XC CHASSIS V-RIDE	Class A	2016 — 2021	RBK18	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA. No XCR chassis.	Reflex	
XC CHASSIS V-RIDE	Class A	2016 — 2021	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	

<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Category</u>	<u>Notes</u>
<b>GILLIG</b>						
DIESEL MODELS	Cutaway/Van	1994 – 2006	RBK6	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
DIESEL MODELS	Cutaway/Van	1994 – 2006	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
GAS MODELS	Cutaway/Van	1986 – 1994	RBK6	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
GAS MODELS	Cutaway/Van	1986 – 1994	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	

<b>GMC</b>						
1500 VAN	Passenger Van	2013 – 2018	RBK23	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
1500 VAN	Passenger Van	2013 – 2018	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
1500 VAN	STEERING BOX OUTSIDE FRAME	1971 – 1995	RBK1	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
1500 VAN	STEERING BOX OUTSIDE FRAME	1971 – 1995	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
1500 VAN	Van/Pick-Up	1995 – 2004	RBK15	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
1500 VAN	Van/Pick-Up	1995 – 2004	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
1500 VAN	Van/Pick-Up WITH DUAL CROSS MEMBERS	2004 – 2013	RBK17	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
1500 VAN	Van/Pick-Up WITH DUAL CROSS MEMBERS	2004 – 2013	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
2500 CLASS C	Class C	2013 – 2018	RBK23	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
2500 CLASS C	Class C	2013 – 2018	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
2500 CLASS C	Class C WITH DUAL CROSS MEMBERS	2004 – 2013	RBK17	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
2500 CLASS C	Class C WITH DUAL CROSS MEMBERS	2004 – 2013	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
2500 CLASS C	STEERING BOX OUTSIDE FRAME	1971 – 1995	RBK1	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
2500 CLASS C	STEERING BOX OUTSIDE FRAME	1971 – 1995	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
2500 CUTAWAY	Cutaway/Van	2013 – 2018	RBK23	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
2500 CUTAWAY	Cutaway/Van	2013 – 2018	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
2500 CUTAWAY	Cutaway/Van WITH DUAL CROSS MEMBERS	2004 – 2013	RBK17	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
2500 CUTAWAY	Cutaway/Van WITH DUAL CROSS MEMBERS	2004 – 2013	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
2500 CUTAWAY	STEERING BOX OUTSIDE FRAME	1971 – 1995	RBK1	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
2500 CUTAWAY	STEERING BOX OUTSIDE FRAME	1971 – 1995	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
2500 VAN	Passenger Van	2013 – 2018	RBK23	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
2500 VAN	Passenger Van	2013 – 2018	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
2500 VAN	STEERING BOX OUTSIDE FRAME	1971 – 1995	RBK1	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
2500 VAN	STEERING BOX OUTSIDE FRAME	1971 – 1995	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
2500 VAN	Van/Pick-Up	1995 – 2004	RBK15	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
2500 VAN	Van/Pick-Up	1995 – 2004	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
2500 VAN	Van/Pick-Up WITH DUAL CROSS MEMBERS	2004 – 2013	RBK17	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
2500 VAN	Van/Pick-Up WITH DUAL CROSS MEMBERS	2004 – 2013	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
3500 CLASS C	Class C	1995 – 2004	RBK15	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	

<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Category</u>	<u>Notes</u>
3500 CLASS C	Class C	2013 – 2018	RBK23	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
3500 CLASS C	Class C	1995 – 2004	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
3500 CLASS C	Class C	2013 – 2018	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
3500 CLASS C	Class C WITH DUAL CROSS MEMBERS	2004 – 2013	RBK17	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
3500 CLASS C	Class C WITH DUAL CROSS MEMBERS	2004 – 2013	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
3500 CLASS C	STEERING BOX OUTSIDE FRAME	1971 – 1995	RBK1	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
3500 CLASS C	STEERING BOX OUTSIDE FRAME	1971 – 1995	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
3500 CUTAWAY	Cutaway	1995 – 2004	RBK15	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
3500 CUTAWAY	Cutaway	1995 – 2004	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
3500 CUTAWAY	Cutaway/Van	2013 – 2018	RBK23	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
3500 CUTAWAY	Cutaway/Van	2013 – 2018	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
3500 CUTAWAY	STEERING BOX OUTSIDE FRAME	1971 – 1995	RBK1	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
3500 CUTAWAY	STEERING BOX OUTSIDE FRAME	1971 – 1995	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
3500 VAN	Cutaway/Van WITH DUAL CROSS MEMBERS	2004 – 2013	RBK17	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
3500 VAN	Cutaway/Van WITH DUAL CROSS MEMBERS	2004 – 2013	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
3500 VAN	Passenger Van	2013 – 2018	RBK23	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
3500 VAN	Passenger Van	2013 – 2018	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
3500 VAN	STEERING BOX OUTSIDE FRAME	1971 – 1995	RBK1	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
3500 VAN	STEERING BOX OUTSIDE FRAME	1971 – 1995	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
3500 VAN	Van/Pick-Up	1995 – 2004	RBK15	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
3500 VAN	Van/Pick-Up	1995 – 2004	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
4500 CLASS C	Class C	2013 – 2018	RBK23	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
4500 CLASS C	Class C	2013 – 2018	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
4500 CUTAWAY	Cutaway/Van	2013 – 2018	RBK23	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
4500 CUTAWAY	Cutaway/Van	2013 – 2018	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
G30	Class C and Cutaway	1971 – 1995	RBK1	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
G30	CLASS C CUTAWAY	1971 – 1995	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
KODIAK C4500	Cutaway	2003 – 2010	RBK5	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
KODIAK C4500	Cutaway	2003 – 2010	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
KODIAK C5500	Cutaway	2003 – 2010	RBK5	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
KODIAK C5500	Cutaway	2003 – 2010	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
P SERIES		1981 – 2006	RSSP30	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
P SERIES	P30/P32/P3500	1998 – 2006	RSSCP30	Replaces OEM dampener.	Reflex	
P SERIES	P30/P32/P3500	1998 – 2006	RSDP30	Replaces OEM dampener. No return-to-center feature.	Reflex	
P SERIES	P30/P32/P3500	1981 – 2006	RBK3	Coil spring IFS (not for widebody). The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSP30.	Reflex	
P72-P92	Class A	1996 – 1997	RBK6	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
P72-P92	Class A	1996 – 1997	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
SIERRA 1500 PICK-UP	2WD SUV	1998 – 2004	RBK15	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSC.	Reflex	
SIERRA 1500 PICK-UP	2WD Van/Pick-Up	1998 – 2004	RSSC	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	

### JOHN DEERE

MOTORHOME CHASSIS	Class A	1986 – 1994	RBK8	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
MOTORHOME CHASSIS	Class A	1986 – 1994	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	

### MAGNUM

BEAVER COACHES	Class A	1994 – 2006	RBK6	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
BEAVER COACHES	Class A	1994 – 2006	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
SAFARI VELVET RIDE	Class A	1998 – 2007	RBK10	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
SAFARI VELVET RIDE	Class A	1998 – 2007	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
SAFARI WITH LEAF SPRINGS	Class A	1994 – 2007	RBK6	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
SAFARI WITH LEAF SPRINGS	Class A	1994 – 2007	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	

### NEWELL

NON-IFS	Class A	1978 – 1990	RBK6	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
NON-IFS	Class A	1978 – 1990	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	

### OSHKOSH

K-LINE	Class A	1980 – 1995	RBK8	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
K-LINE	Class A	1980 – 1995	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
M-LINE	Class A	1980 – 1995	RBK8	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
M-LINE	Class A	1980 – 1995	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
TORSION SUSPENSION	Class A	1994 – 1994	RBK6	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
TORSION SUSPENSION	Class A	1994 – 1994	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
Z-LINE	Class A	1980 – 1995	RBK8	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
Z-LINE	Class A	1980 – 1995	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	

### ROADMASTER

AIR RIDE	Class A	2000 – 2017	RBK6	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
AIR RIDE	Class A	2000 – 2017	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
MONACO	Class A EXCEPT DANA SPICER FRONT AXLE	2000 – 2017	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
MONACO	EXCEPT DANA SPICER FRONT AXLE	2000 – 2017	RBK6	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
STRAIGHT AXLE LEAF SPRING	Class A	2000 – 2009	RBK8	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
STRAIGHT AXLE LEAF SPRING	Class A	2000 – 2009	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	

### SPARTAN

EC200	Class A P-LINE	1993 – 2007	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
EC200	P-LINE	1993 – 2007	RBK6	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
EXP CHASSIS	Class A	2000 – 2004	RBK6	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
EXP CHASSIS	Class A	2000 – 2004	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	



<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Category</u>	<u>Notes</u>
MOUNTAIN MASTER	Class A NON INDEPENDENT FRONT SUSPENSION	1993 – 2007	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
MOUNTAIN MASTER	NON INDEPENDENT FRONT SUSPENSION	1993 – 2007	RBK7	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
N-LINE	Class A	1991 – 2007	RBK7	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
N-LINE	Class A	1991 – 2007	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
WC SERIES	Class A	1999 – 2006	RBK7	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
WC SERIES	Class A	1999 – 2006	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	

### **WORKHORSE**

P SERIES		2000 – 2005	RSSP30	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
P SERIES	Class A P30/P32/P3500	2000 – 2005	RSSCP30	Replaces OEM dampener.	Reflex	
P SERIES	Class A P30/P32/P3500	2000 – 2005	RSDP30	Replaces OEM dampener. No return-to-center feature.	Reflex	
P SERIES	Class A WITHOUT OEM STEERING DAMPENER	2000 – 2005	RBK3	Coil spring IFS (not for widebody). The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSP30.	Reflex	
R SERIES	Class A NON-INDEPENDENT FRONT SUSPENSION	2003 – 2007	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
R SERIES	NON-INDEPENDENT FRONT SUSPENSION	2003 – 2007	RBK13	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
W SERIES CHASSIS	Class A W16,W18	2006 – 2012	RBK8	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
W SERIES CHASSIS	Class A W16,W18	2006 – 2012	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	
W SERIES CHASSIS	Class A W20,W22,W24	2000 – 2012	RBK13	The RBK sku listed is for the mounting kit only. Be sure to order this AND the steering stabilizer part number RSSA.	Reflex	
W SERIES CHASSIS	Class A W20,W22,W24	2000 – 2012	RSSA	Steering Stabilizer only. You will also need to order a corresponding RBK kit in order to install this product.	Reflex	

## Application Guide Notes Key

- 1 · Modification may be required.
- 2 · Welding required.
- 3 · 1992 to mid-1995 have IPD-style bars with rubber bushings. Mid-1995 on have IPD-style bars with urethane bushings.
- 4 · 18,000 lbs. GVWR and under.
- 5 · Will not fit Newmar motorhomes.
- 6 · Not for Oshkosh X, V, M or T line chassis (check with manufacturer for your model using VIN#).
- 7 · 1991 and older require factory retro fit conversion kit.
- 8 · Will Work with air bags.
- 9 · With autochains and with and without air brake.
- 10 · Will fit 1992-99 models with 4WD. For vehicles with factory sway bar for Suburban and 4 door Tahoe/Yukon – not for 2 door models.
- 11 · Will fit 1999 models. For vehicles without factory bar. For Suburban and 4-door Tahoe/Yukon. Not for 2 door models.
- 12 · For 2000-on GMC Yukon XL and Chevy Suburban (leaf springs 2500/3500 series) not for regular Yukon or Tahoe (coil springs – 1500 series).
- 13 · For 2000-on Chevy/GMC 2500, 2500HD and 3500 (fits both single and dual rear wheels) pickups. Both gas and Duramax diesels. Will work with airbags.
- 14 · Fits 80-2003 3/4 ton and 1 ton vans.
- 15 · For 1975-03 Motor home chassis can be used on heavily loaded 1 ton vans.
- 16 · 2003-06 Dodge 4WD pickups 2500 and 3500 models, both single and dual rear wheels. For stock ride height vehicles. May not fit with 5th wheel hitch.
- 17 · 1996-02 4WD 2500 and 3500 pickups. Not designed for 2WD.
- 18 · For 1975-91 only. Not for E150.
- 19 · Fits 1975-2006 Motor homes and emergency vehicles. Will still work on 2005 gas E-series van cutaways.
- 20 · For E350 DRW (dual rear wheels/cutaway) chassis 1975-2003 with automatic chains. Nor for use on diesel or V-10 models.
- 21 · For 1975-2003 Ford E350 vans without chains. Type 2 Ambulance or Class B Motor home.
- 22 · 1992-2006 also fits E-Super Duty, sometimes called E450. This kit has offset endlinks for tie rod clearance. Does not fit E250 or E150.
- 23 · For 1988-91 F53 motor home chassis. Not for 1992 or newer motor homes. Also F450 pickup cab/chassis. 1986-97 to replace factory sway bar if not factory bar, additional parts will be needed (see Ford Dealer).
- 24 · For 1992 models and newer vans (Type 2 Ambulance/Class B Motor Homes) except Powerstroke diesels and V-10 models. The exhaust is in the way! Kit could be mounted if customer is willing to modify exhaust.
- 25 · For V-8 chassis and V-10 chassis with GVWR of 18,000lbs or less. The 4th digit of the VIN is L or M. GVWR is found on chassis data plate/sticker. These axle U-bolts are spaced 5-inch wide by 5.25-inch front to rear (Dana 80 axle). Will work with a tag axle if the drive axle has leaf springs.
- 26 · For 1998-on F53 with V-10 engine and GVWR greater than 18,000 lbs. The 4th digit of VIN is N. GVWR is found on chassis data plate/sticker. U-bolt spacing is 5-inch wide by 6.25-inch front to back (Dana S135 rear axle). Will work with a tag axle if the drive axle has leaf springs.
- 27 · Will work on the new 6 liter diesel engine for E450 chassis 1997-on. Mounts to axle same as factory bar.
- 28 · For 1999-2003 F250/350 pickup single rear wheels with factory sway bar (both 2WD and 4WD). <br> If the vehicle does not have a factory bar, you need endlink kit 590230-00.<br> If a 4" lift kit is installed, you will need endlink kit 590039-00. Will not fit 2004 or any dual rear wheels. Bar mounts under differential, not over differential like stock sway bar.
- 29 · Front sway bar kit for 2000-04 Ford F250-F350 trucks with straight axle (all 4WD models and F450 with front leaf springs, and F550 2WD models). Replaces factory sway bar. Must have factory sway bar. Will not fit 2005-on with coil spring front suspension. Updated to exclude 1999 models. Will fit 1999 model when factory bar is present (added 1/2-inch hardware for 99 model year)
- 30 · Front sway bar kit for 2005-on Ford F450-F550 4WD trucks with coil spring axle. Replaces factory sway bar. Must have factory sway bar. Will only fit cabin chassis, not for pickups.
- 31 · Rear sway bar kit replaces factory sway bar. For F350 commercial cab/chassis (only Dana 80 rear end with shock bracket welded to axle). Will not fit any pickup. On F450 confirm Dana 80 axle (round axle tubes). If axle tubes are square (Dana 120) use kit #1139-161.

<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Category</u>	<u>Notes</u>
32	Rear sway bar for 2000-08 F550 cab/chassis. Replaces factory bar. Also fits F450 with Dana 120 axle (square axle tubes).					
33	Rear sway bar for 1999-2007 F250 and F350 2WD and 4WD pickups with dual rear wheels and factory sway bar. Designed to replace factory sway bar. If a 4-inch lift kit is installed, you will need endlink kit 590038-00.					
34	For chassis with true air brakes with air canister on the axle. Some chassis have air assist brakes or air over hydraulic brakes, these are not true air brakes.					
35	Rear sway bar kit for Spartan Verst, air suspension. 1996-on 1.5-inch diameter. Will not fit Renegade made by Harney Coach. Leveling jacks are in the way.					
36	For Spartan Verst air suspension. 2004-on.					
37	Fits Mountain Master M11 Verst Chassis.					
38	For FL series chassis with 8,000lbs front axle and 19.5inch rims or 126" wheel height. Normally used on FL50 or FL60 series low profile trucks (most ambulance chassis). This will not work with the new Cat diesel engine introduced in 2000.					
39	For FL50 & FL60 ambulance chassis with Hendrickson air ride rear suspension. Will not work with chains (use 1209-104).					
40	For Freightliner FL50/FL60 chassis with automatic chains. Proven to fit with Onspot. Arms of bar face towards rear of truck for Hendrickson suspension only.					
41	For chassis up to 1998 and some 1999 and newer with long 3/4-inch diameter. U-bolts on rear axle. Have customer or shop measure u-bolt diameter. For chassis with short 7/8-inch diameter U-bolts (most of 1999-on) use kit 1209-115. If the rear suspension does not have U-bolts (late 2003 and up), use kit 1169-236.					
42	For 2000 and newer FL50/FL60/M2 vehicles with Airliner suspension. If vehicle has Hendrickson rear air suspension, use 1209-101 for vehicles without automatic tire chains, or 1209-104 for vehicles with automatic tire chains. Not for Class A motorhomes.					
43	Front-facing sway bar. Not for use with automatic tire chains. If vehicle is equipped with automatic tire chains, use 1209-106.					
44	Rear-facing sway bar.					
45	For most 1999-2003 Freightliner XC. This kit is for chassis with short 7/8-inch diameter bolts on rear axle. NOTE: sometime in 2003, Freightliner suspension changed to a style with No U- bolts. Have customer/shop measure U-bolt diameter. For chassis with 3/4-inch diameter U-bolts (mostly up to 1998) use kit 1209-105. If the rear suspension does not have U-bolts (late 2003 and up), use kit 1169-236.					
46	Will not work on chassis with Mercedes Benz engines that have auxiliary cooling package. If standard cooling, it is okay.					
47	Update of kit 1259-106 now fits all years for Rear W22 Workhorse chassis. Also fits W20 chassis.					
48	Fits GM 1/2 ton SUV chassis; coil springs only.					
49	Will not fit with auto chains					
50	Only fits vehicles with gas tanks that are rear of the axle.					
51	Currently does not work with Super Hitch					
52	This kit uses a flat plate that is held in place by the leaf spring U-bolts on the rear axle. Check to ensure there is enough exposed U-bolt below the nut to accommodate the factory nut and washer once our 1/2-inch thick plate is installed above them. If you do not have enough exposed U-bolt, order one of our U-bolt replacement kits.  For U-bolts with a square top, order kit 590050-00. For U-bolts with a round top, order kit 590050-10.					
53	If superhitch is installed, the 590051-00 bracket kit is needed					
54	For use with Duramax diesel only.					
55	When air bags have been added you will need the 590054-00 adapter kit which requires welding.					
56	For Spartan Mountain Master Verst air suspension chassis Tuthill 240AR with jacks located to the rear of the cross member.					
57	Will work with Kelderman air ride, Will work with Link Ultra ride.					
58	Chassis must have 3" square beam connecting the 2 airbags located underneath.					
59	Rear Leaf Spring hanger brackets may be bolted or riveted on. When riveted, install time will increase. Manufacture codes can be found under the driver side visor: EV8 = Rivets ; EV9 = Bolts.					
60	Will not work with air bags.					
61	Must have factory swaybars.					
62	When installing with Link UltraRide or Kelderman Air Ride kits, two B315 endlinks will be need to be ordered separately.					
63	2007 Model year vehicles manufactured in or after June may have 2008 Chassis. Please confirm before ordering.					
64	Will work with other model years that have the inverted Y front steering system with factory dampener.					
65	Will work with automatic tire chains.					
66	When no factory bar is present, customer will need to purchase kit 590170-00.					

<u>Model</u>	<u>Sub-Assembly</u>	<u>Year</u>	<u>Item #</u>	<u>Comments</u>	<u>Category</u>	<u>Notes</u>
67				For Applications Without onspot chains use 1179-110 and 590060-00.		
68				Chassis built before June of 2007 will require an additional axle mounting bracket kit part 590061-00.		
69				Will NOT fit with Goose Neck Hitch.		
70				If unit has no sway-bar from factory you will need mount kit 590064-00 (Factory mount kit).		
71				Some Airstream chassis have a propane tank inside the frame between the frame and drive line the 1209-131 will not fit with this model (please check before ordering).		
72				Vacationer and La Palma models will require axle bracket kit 590063-00.		
73				This kit will not work on vehicles with factory-equipped air suspension systems.		
74				If a 4-inch lift kit is installed, you will need endlink kit 590045-00.		
75				Chassis model year may vary from RV model year. Verify chassis model year before ordering.		
76				A five ton or greater capacity jack is required for this installation.		
77				The anti-sway bar in this kit has been thoroughly heat-treated and is designed for bed campers or heavy hauling situations.		
78				This kit will only work on vehicles with a factory-installed front sway bar.		
79				Fits 4x4 models only.		
80				This kit requires Source Engineering rear control arm part number TRA-1004.		