Installation is as easy as 1, 2, 3

Step I

Position Even Brake between the seat and the brake pedal. Adjust the Even Brake pedal clamp over the brake bedal.



Step 2

Move the driver's seat up to Even



Step 3

Plug in the wiring harness cord, the power cord and press the Test button.

Ready...Set...Tow!







Portable Proportional Braking System

Additional Features

- Automatic brake protection the monitor alerts you after an extended period of continuous braking, then Even Brake releases braking pressure, avoiding excessive wear on the towed vehicle's brakes.
- · Automatically delivers maximum braking pressure in an emergency or a break away situation — Even Brake works the most when you need it the most.
- Easily adjusts to individual braking preferences adjust braking force and sensitivity at the touch of a button.
- On-board memory even when unplugged, Even Brake will remember your adjustment settings and will automatically level itself.
- Completely portable easily transfers from vehicle to vehicle without expensive labor fees; connects and disconnects in seconds.
- Small and lightweight fits virtually all vehicles, with plenty of "elbow room" under the steering wheel and dash.
- High-capacity air compressor recovers quicker ready for the next stop nearly twice as fast as other systems.
- · Adjustable brake pedal clamp fits brake pedals that other systems can't.
- Adjustable monitor lights bright for daytime driving; dimmer switch allows the monitor lights to be dimmed for nighttime driving.
- Four independently adjustable feet for a stable platform in vehicles with uneven floors.



Towing and Suspension Solutions

ROADMASTER, Inc. • 6110 NE 127th Ave • Vancouver, WA 98682 800-669-9690 • roadmasterinc.com

© 2007-2014 ROADMASTER, Inc. • All rights reserved • 853708-04 01.14 All illustrations and specifications contained herein are based upon ROADMASTER, Inc. reserves the right to make changes at any time without notice, in material, specifications and models




EVEN®BRAKE®

Portable Proportional Braking System

Even Brake is the ultimate portable, proportional towed vehicle braking system. It automatically increases or decreases braking pressure in direct proportion to the motorhome. In other words, it brakes evenly — at the same time, and at the same intensity, as you brake the motorhome.

Proportional braking is a distinct advantage over 'on-or-off' systems, which brake at one preset level, no matter how hard the motorhome stops. Even Brake delivers full emergency braking when you need it, and won't cause excessive brake wear when you don't.





The Features you want... the Safety you need!

Even Brake monitor

Even Brake's monitor gives you complete, continuous braking information — at a glance.

Even Brake stays in constant communication with the motorhome, and with you. It reports any braking activity, or a change in system status, to a wireless monitor in the motorhome.







The monitor SHOWS you —

- An LED display across the top of the monitor illuminates when Even Brake is applying the brakes, or if there is any change in the braking system. The LED display is a quick, visual reference — a green, yellow or red light.
- Simultaneously, an LCD text message directly below the LED explains the current braking condition, in complete detail.

The monitor TELLS you -

 In addition to the LED display and the LCD text message, an audio tone will alert you to an emergency braking condition.

Other Exclusive Features

- Full-time proportional braking proportional braking is even braking — your towed vehicle's brakes respond to your motorhome's brakes, at the same time and at the same intensity.
- Constant self-diagnostic testing Even Brake monitors its own performance constantly, and any change in system status is transmitted to the motorhome monitor. Even Brake is the only supplemental braking system that checks itself, so you don't have to — a glance at the monitor assures you that Even Brake is fully operational.
- 'Power Save' low battery protection Even Brake warns you of a low battery in the towed vehicle with LED and LCD alerts at the motorhome monitor; giving you time to recharge the battery. If the battery' voltage doors too low Even Brake goes into sleep